

70mm CENTRALISER BRUSHES Model No CE110

A 70mm Centraliser is shown below with a 46mm Camera along with 15mm Brushes. 40mm Brushes can also be installed in the same Centraliser. M6 Securing Bolt secures the Camera into the Centraliser (see picture 2). Once the Camera is installed in the Centraliser, connect the Camera to the Pushrod along with the Spring ready for deployment.

In order to change out the 40mm Brushes, slacken 2 x M4 Grub Screws per Brush, re-insert larger Brushes and secure.

Once work is finished, please remove the Centraliser from the Camera and wash with fresh water.

